



Loving music

Important Safety Instructions



1. General Information

- Read and retain these instructions for future reference. Observe and follow all guidelines provided.
- Not suitable for children under 6 years! The package may contain small parts that could be swallowed.
Risk of suffocation from plastic films and small parts. Keep films, bags, straps, etc., out of the reach of children to prevent suffocation.
Children can strangle themselves with cables. Store cables out of children's reach.
- Inspect the device for damage before use. Do not operate the tonearm if it is damaged. Repairs or maintenance are required if any damage is present. Examples include liquid or objects entering the device, exposure to rain or moisture, improper functioning, or being dropped. Contact your dealer to have the device inspected.

2. Intended Use

Tonearms are designed exclusively for music playback and for use on turntables.

The intended use of the tonearm involves operation in accordance with the information provided in the user manual.

3. Placement

Avoid locations with direct sunlight, temperature fluctuations, or high humidity. Do not place electronic devices near heaters, heat lamps, or other heat-generating devices. The device is intended for use in heated indoor spaces.

4. Maintenance

- Never oil or treat the precision bearings with other fluids.
- The nuts securing the precision bearings and the screws for fastening the signal cable are perfectly adjusted at the factory and should not be altered.
- To clean the glass tube, use cotton swabs and a standard glass cleaner. Apply glass cleaner to the swab and move it from the "lead-in groove" to the "lead-out groove" (edge of the platter to the center of the turntable).
- Do not use aggressive cleaning agents.
- Do not use dry cloths for cleaning, as this can generate static electricity. Suitable cleaning and care products from **Clearaudio** are available at www.analogshop.de or through authorized dealers.
- Use only a soft cloth with a smooth surface or a soft brush for cleaning.

5. Health Warnings

- Prolonged exposure to high volume levels can cause hearing damage. Use high volumes responsibly.
- Risk of injury from sharp objects.



Loving music

Important Safety Instructions

6. Disclaimer of Liability:

Use only accessories approved by the manufacturer.

Warranty claims will be void if damage is caused by failure to follow the instructions in the manual. The manufacturer assumes no liability for consequential damages.

Liability Disclaimer:

Clearaudio assumes no liability for damage to sound carriers caused by improper handling!

7. Service

- Do not open the casing to access internal electronics, as there are no user-serviceable parts inside.
Opening the device may void the warranty. Repairs and maintenance should only be performed by qualified personnel.
- The tonearm may only be repaired by the manufacturer during the warranty period; otherwise, the warranty will be void.
Service for all **Clearaudio** products should be carried out exclusively through authorized dealers. If service is required despite the high manufacturing standards, the **Clearaudio** product must be sent to **Clearaudio** through your dealer.
- If functional issues occur, contact the dealer where you purchased the device. Do not use the product again until repairs are complete.

8. Transport

- Always use the original packaging when transporting the **Clearaudio** tonearm. Ensure the device is packed as it was delivered.
- Proper packaging is essential to ensure safe transport.
- To prevent the tonearm carriage from moving uncontrollably during transport, secure it with a piece of foam or similar material. Use only the original packaging for shipping the tonearm. When packing and disassembling the tonearm, follow the instructions in reverse order.

Clearaudio assumes no liability for transport damage caused by improper packing.

10. CE Compliance

This product complies with the requirements of European directives and other applicable regulations.





Loving music

Important Safety Instructions

11. Disposal

For customers in Europe:

Disposal of electrical and electronic waste, as well as batteries and accumulators.



a) If a product, packaging, and/or accompanying documentation is marked with the symbol of a crossed-out trash bin, the product is subject to European directives and national laws implementing these directives.

b) These directives and laws require that electrical and electronic waste, as well as batteries and accumulators, must not be disposed of with regular household waste. Proper disposal, recovery, and recycling must be ensured, and you are obligated to dispose of old devices and discharged batteries/accumulators at designated collection points.

c) Proper disposal contributes to conserving valuable resources and prevents potential harmful effects on public health and the environment that may result from improper disposal. Disposal is free of charge.

d) For more information on the recycling and recovery of old devices, batteries, and accumulators, contact your local municipality, the waste disposal company, or the point of sale where you purchased the product.